

Heavydrive[®].com

YOUR TRANSPORT AND LIFTING SPECIALIST



VSG 600 KL B

Operating Instructions



Contents

Foreward	1-1
Technical description	1-2 / 1-3
Basic safety information	2-1
Warning instructions and symbols	2-1
Authorised use	2-1
Organisational measures	2-2
Personnel selection and qualifications	2-3
Safety instructions regarding particular operating stages	2-3
Normal operation	2-3
Special work	2-4
Safety instructions for special types of danger	2-4
Electrical energy	2-4
Oils, greases and other chemical substances	2-4
Commissioning	3-1
Charging the battery	3-2
The control elements	3-3
Assembly of the extensions with support suckers	3-4
The manual valve (suction / release valve)	3-4
Before transporting	3-5
Operation	4-1
Switching on	4-2
Working cycle	4-3 / 4-4
Switching off	4-5
Charging the battery	4-5

Troubleshooting	5-1
Pumps no longer perform correctly	5-1
Leak check for the entire system	5-2
Electrical malfunction	5-3
Vacuum pumps do not start when the device is actuated	5-3
Vacuum pumps do not switch off when vacuum of -0.72 bar is reached	5-3
No warning signals	5-3
Maintenance	6-1
The suckers	6-1
The vacuum lines	6-1
Leak check	6-2
The vacuum pump	See appendix
Technical data	7-1
Dimensioning outer edge of suction pad, overall depth	7-2
Carrying capacity of the VSG 600 KL B	7-3
Wiring diagram of the VSG 600 KL B	7-4
Wiring diagram of the VSG 600 KL B with radio remote and cable remote control	7-5
Options for the VSG 600 KL B	
Lowering cylinder	8-1
Remote control with cable	8-1
Remote control with radio control	8-2
Spare parts list	9-1
Test report suction pads T-15 / T-15W	See appendix
Dimensions of the VSG 600 KL 6 B	9-2

Foreword

These operating instructions are intended to help you become familiar with the VSG 600 KL B and to use it as intended.

These operating instructions contain important instructions about operating the VSG 600 KL B safely, effectively, and economically. Observing them helps to avoid repair costs and down time and to increase the reliability and working life of the VSG 600 KL B.

These operating instructions must be supplemented by additional instructions due to existing national accident prevention regulations.

These operating instructions must always be available at the site of use of the VSG 600 KL B

These operating instructions must be read and observed by every person responsible for doing work on the VSG 600 KL B for example:

- operation, including equipping, troubleshooting during operation, removal of production waste, care
- maintenance (servicing, inspection, repair) and/or
- transport.

In addition to the operating instructions and binding accident prevention regulations applicable for the country of use and the application case, the recognised technical rules for safe and professional work must also be observed.



If you discover errors when reading these operating instructions, or if you have further comments or suggestions, please contact:

Heavydrive LLC
3414 Peachtree Road NE, Suite 1500
Atlanta, GA 30326
Phone: +1 470 407 4352

The management appreciates your cooperation.

Technical Description

The VSG 600 KL B is a combination of two vacuum pumps with power supply (battery or mains, including charger) and a vacuum cross arm with two vacuum circuits working independently from each other. This vacuum cross arm has a single row of suckers and is intended for flexible use on construction sites, anywhere where no 220 to 240 volt connection is available. Using the VSG 600 KL B the transported goods can be rotated 360 degrees and also be swivelled 90 degrees. The VSG 600 KL B is hung on a crane hook and is supplied with energy via the installed battery. In addition to easy installation on a crane or similar device, the VSG 600 KL B also offers the safety advantage that in general no vacuum supply hose or voltage supply line is required as is the case with separated devices (cross arm, vacuum pump). In addition, it is also possible to lower transported goods during a power outage with this type of device as long as both vacuum circuits are perfectly sealed, because the vacuum reserve tanks are located on the vacuum cross arm.



In detail, the device consists of a rectangular pipe frame with a suspension eye, the basic frame. A casing is connected to this basic frame first via a swivelling joint and then via a rotating joint. This casing is the carrier frame and holds the two vacuum reserve tanks and the vacuum pumps, the battery charging device and the battery and the suckers. The sucker connections are supplied with a vacuum (suction) or normal compressed air (release) by means of the sliding valves of the two vacuum circuits. Two inspection vacuum meters provide information on the exact pressure ratios in the vacuum lines to the individual suckers. A voltage display indicates the battery charge level.

The charging circuit voltage for the charger is 220-240 volt AC (50/60 Hz).

Two vacuum pumps are used to generate the vacuum (one vacuum pump per vacuum circuit). The vacuum pumps work without oil lubrication and are therefore maintenance-free.

In order to avoid draining the battery unnecessarily, the pump switch has a two-point controller that switches off the vacuum when the pressure reaches -0.72 bar in the vessel, switches the pumps off and switches the pumps back on when the pressure falls below approx. -0.68 vacuum. This avoids premature draining of the battery due to the pumps being allowed to run unnecessarily. The battery is maintenance-free and enclosed; they are totally discharge-safe.

Mode of operation

Switch the machine to On using the ON/OFF switch. Then set the two manually operated suction/release valves to RELEASE. The vacuum cross arm must be positioned on the load to be transported in such a way that all suckers are flat on the smooth clean surface so that the sucker lips can seal completely. Set both suction/release valves to SUCTION one after the other and wait until the pumps of both vacuum circuits switch off. You can check the vacuum using the vacuum meters 1 and 2 on the device. If there is a vacuum of -0.72 bar in each vacuum circuit, the load can be transported. To release the suckers from the load, set both suction/release valves to RELEASE:

Caution

The VSG 600 KL B must **NEVER** be commissioned with only **one** functional vacuum circuit.

Basic safety information

Warning instructions and symbols

The following terms and symbols are used in the operator's manual for especially important information:

- Note** Special information regarding the economical use of the device
- Caution** Special information regarding requirements and prohibitions for preventing damage.
- Danger** Information or requirements or prohibitions for protecting people or preventing extensive damage.

Authorised use

The VSG 600 KL B has been constructed in accordance with the state of the art and recognised safety regulations. Nevertheless, its use may result in danger to life and limb of the operator or third parties and impairment of the machine or other property may occur.

The machine may only be used when in technically perfect condition, as authorised. The user must be conscious of safety and risks and act in accordance with the instructions. Failures which can interfere with safety must be eliminated immediately.

The VSG 600 KL B is exclusively for transporting gas-tight, dry materials with firm, flat surfaces. Other use or use going beyond this, for example transporting gas-permeable materials, film-covered materials, wet materials, or rotating or swivelling large or heavy transported goods is not authorised. The manufacturer/supplier is not liable for the damages resulting from this. The risk is carried by the user.

Use as authorised use also includes complying with the operating instructions and the inspection and maintenance conditions.

Organisational measures

Always keep the operating instructions within reach at the site of use.

In addition to the operating instructions please observe and teach any other generally applicable statutory regulations concerning accident prevention.

Such obligations can also include providing and wearing personal protective equipment.

Please supplement the operating instructions with instructions including supervision and reporting obligations taking into consideration operational corporate circumstances, e.g. relating to work organisation, work processes, personnel used.

The personnel authorised to operate the device must read the operating instructions, particularly the chapter about safety instructions before starting work. It is too late to read the instructions if work has already been started. This applies in particular to personnel who only work on the machine occasionally, e.g. for equipping it and carrying out maintenance work.

Occasional checks should be carried out to ensure that the members of personnel follow the instructions and work in a safety-conscious manner and are aware of risks.

If necessary or if required by regulations, personal protective equipment should be used. Glass should only be transported with the appropriate protective equipment (safety shoes, protective gloves, wrist protectors, helmet etc.) A helmet should be worn at all times when transporting goods above head height.

All safety and danger instructions on the device should be complied with.

All safety and danger instructions on the device should be kept complete and in legible condition.

If there are any safety-related changes to the device or its operation, the device should be stopped immediately and the malfunction should be reported to the relevant office or person.

No changes, attachments or upgrading work that could possibly impair safety should be carried out on the machine without the consent of the supplier. This also applies to the installation and setting of safety equipment and valves as well as to welding on load-bearing parts.

Spare parts must fulfill the technical requirements specified by the manufacturer. This is always guaranteed with original replacement parts.

Vacuum hose lines should be replaced at the specified intervals or at appropriate intervals, even if there are no recognisable safety defects.

Compulsory deadlines or those specified in the instructions for recurring tests / inspections should be complied with

Appropriate workshop equipment is absolutely necessary for performing the maintenance measures.

Personnel selection and qualification

Work on/with the machine may only be performed by reliable personnel. The legal minimum working age should be observed.

Use only trained or instructed personnel; responsibilities among personnel should be clearly established for operation, equipping, maintenance, and repair.

Ensure that only authorised personnel works on the machine.

Specify a person who is responsible for operating the machine and give him/her the opportunity to refuse to comply with the safety instructions of third parties.

Personnel being trained or instructed, or who are taking part in a general training programme, may only work on the machine when under the constant supervision of an experienced person who is familiar with this situation.

Work on the electrical equipment of the machine may only be performed by an electrician or by trained personnel under the direction and supervision of an electrician in accordance with the rules of electrical engineering.

Safety instructions on particular operating phases

Normal operation

Avoid all unsafe work practices.

Before starting work, become familiar with the working environment at the site of use. The working environment includes impediments in the work and traffic area, the load bearing capacity of the floor, and cordoning off the worksite from public traffic areas.

Take measures to ensure that the machine is only operated when safe and functional.

Check the machine for externally recognisable damages and flaws at least once per shift. Report any changes that occur (including those to the operating behaviour) immediately to the responsible office/person. If necessary, stop the machine immediately and secure it!

During malfunctions, the machine should be stopped immediately and secured. Malfunctions should be corrected immediately.

The switching on and off procedures should be complied with, and the inspection displays should correspond to the operating instructions.

Always stop work if it becomes dark or if visibility is poor!

Special work

The setting, maintenance, inspection activities and deadlines, including information on replacement of parts and modules stipulated in these operating instructions must be observed. These activities may only be performed by authorised specialists.

Only perform maintenance and repair work when the machine is positioned on flat ground with sufficient bearing capacity and is secured so that it cannot roll away or collapse.

Clean machines, particularly connections and screw connections at the beginning of maintenance/repair work. Do not use aggressive cleaning agents! Use lint-free cloths for cleaning.

Never clean the machine with water or steam jet (high-pressure cleaner).

After cleaning, inspect all vacuum lines for leaks, loosened connections, abrasion and damage. Repair any flaws immediately!

Always tighten screw connections loosened during maintenance and repair work.

Safety instructions for special types of danger

Electrical power

Use only original fuses with the specified current strengths. Switch off the machine immediately during malfunctions to the electrical energy supply.

Work on electrical equipment or operating materials may only be performed by an electrician or by trained personnel under the direction and supervision of an electrician in accordance with the rules and regulations of electrical engineering.

Machine and system parts on which inspection, maintenance, or repair work must be performed, must be switched free of current if required. First check the switched off parts to ensure that they are free of voltage, then ground and short-circuit them, and insulate neighbouring live parts.

The electrical equipment of the machine must be checked regularly. Flaws such as loose connections and melted cables must be repaired immediately.

Oils, greases, and other chemical substances

Observe the safety regulations applicable for the product when using oils, greases, and other chemical substances!

Commissioning

Note

- Do not store the VSG 600 KL B in a damp or very cold (frost) environment. Otherwise there is no guarantee that the installed pumps will function properly.

Caution

- Always ensure that the suckers are not placed on sharp edges because this could damage the sucker lips. This would lead to leaks in the suction circuit, impairing the functioning of the device.
- Never place the machine with mounted suckers with the rubber surfaces of the suckers on sandy or similar ground. This could damage the sealing lips of the suckers. This would lead to leaks in the suction circuit, impairing the functioning of the device. Or the grains of sand or similar substances could be pressed into the rubber surfaces, leading to damage to the upper surface of the transported goods.

Danger

- Do not allow heavy rain to fall on the VSG 600 KL B
- Do not place the VSG 600 KL B in water.
- Do not convey loads over persons or machines. Cordon off the area under hanging transported goods with wide clearance.

Charging the battery

Check the VSG 600 KL B for any externally recognisable damages or flaws.

Compare the connection on the power supply network and check the voltage, current and mechanical connection (plug connection) with the necessary data for the vacuum pumps. If they do not correspond, the machine may not be operated.

Connect the VSG 600 KL B to the supply network using an extension cable.

The charging procedure can be checked in the voltage display after pressing the test button.

After the charging procedure is completed, a value of 100% must be visible in the voltage display when Test button is pushed.

The battery is charged after a maximum of 24 hours.

Remove the extension cable from the supply network.

This completes the charging procedure.


Note

After the transporting work is completed, switch the device off with the switch in order not to drain the battery unnecessarily.

If the battery is not charged, the VSG 600 KL B cannot be used in mains operation.

During the charging procedure, the VSG 600 KL B must be switched off. This means that you should not work with it as the charging device or the battery will be damaged.

The control elements



1. Suction Cup T 15
- 2 . 2 Pieces, Removable Widening
- 3 Vacuum line, blue = vacuum circuit 1 / Black = Vacuum circuit 2
- 4 Vacuum coupling, blue = vacuum circuit 1
- 5 Vacuum coupling, black = vacuum circuit 2
- 6 Front panel left
7. Lowering cylinder
- 8 Suspension
- 9 Suspension on the upper frame
- 10 Swivel Lock
11. Front Panel Right
- 12 Power Plug
- 13 Horn
14. 10-pin connector, for remote controls
- 15 Manual valve (suction/release valve) Suction circuit 2
- 16 Locking mechanism
17. Turntable
- 18 Manual valve (suction/release valve) Suction circuit 1
- 19 Top frame


Options

- 20 Flashing light for remote control Suction, quick-release function
21. Radio receiver
- 22 Radio remote control for releasing
- 23 Radio remote control for vacuuming and releasing with quick-release function
24. Wired remote control for release
25. Wired remote control for vacuuming and release with quick-release function


Assembly of the extensions with the support suckers

Push and screw the extensions of the support suckers into the carrier frame (4 x Pos. 21).

The vacuum connection is produced via the quick-lock couplings (20).



The manual valve (suction/release valve)



1. Slide valve, position for suction
2. Slide valve, position for release

Before transporting

Check the VSG 600 KL B for any externally recognisable damage or flaws.

Attach the VSG 600 KL B to the crane hook or similar.

Set the two manually operated suction/release valves to the RELEASE position.

Switch the device on using the main switch.

The yellow control lamp ON signals that the pumps are ready for operation.

The pumps must start up if the vacuum in the vacuum tank is insufficient. After a short time, a vacuum of -0.65 bar should have formed in each tank. When approx. 0.72 vacuum is reached, the vacuum pumps switch off. This should happen after a short time.

Caution

As long as no transport goods are sucked on, the signal tone signals insufficient vacuum in the lines to the suckers, the vacuum control lamps are off and there is no way of inspecting via the vacuum obtained on the two vacuum control meters.

In order to check the vacuum, either a larger plate or several smaller plates of a gas-impermeable material must be present. These are held onto the individual suckers and are then sucked on. In order to do so, the suction/release valves must be set to SUCTION one after the other. When approx. 0.72 bar vacuum has been obtained, the vacuum pumps switch off. It is possible to check via the two control vacuum meters. The signal tone goes out and the vacuum control lamps are lit.

When this happens, the machine switch must be switched off.

Read the achieved vacuum from the two inspection vacuum meters and compare it with a reading taken about 15 minutes later. If there is no discrepancy, the device is leak-tight and safe to operate. If a discrepancy of more than 5% occurs, is not in working order and must not be commissioned. The leak must be eliminated immediately and/or the porous material must be replaced.

Commissioning is complete once the machine switch has been switched back on.

Caution

The attached support suckers must be checked to see whether they are leak-tight.

Caution

The VSG 600 KL B must **NEVER** be commissioned with only one functional vacuum circuit.

Operation

Note

- Do not store the VSG 600 KL B unit in a damp or very cold (frost) environment. Otherwise there is no guarantee that the installed pumps will function properly.

Caution

- Always ensure that the suckers are not placed on sharp edges because this could damage the sucker lips. This would lead to leaks in the suction circuit, impairing the functioning of the device.
- Never place the machine with mounted suckers with the rubber surfaces of the suckers on sandy or similar ground. This could damage the sealing lips of the suckers. This would lead to leaks in the suction circuit, impairing the functioning of the device. Or the grains of sand or similar substances could be pressed into the rubber surfaces, leading to damage to the upper surface of the transported goods.

Danger

- Do not allow heavy rain to fall on the VSG 600 KL B
- Do not place the VSG 600 KL B in water.
- Do not convey loads over persons or machines. Cordon off the area under hanging transported goods with wide clearance.

Switching on

Set the two manually operated suction/release valves to the RELEASE position.

Switch the device on using the main switch.

The yellow control lamp ON signalises that the pumps are ready for operation.

The pumps must start up if the vacuum in the vacuum tank is insufficient. After a short time, a vacuum of -0.65 bar should have formed in each tank. When approx. 0.72 vacuum is reached, the vacuum pumps switch off. This should happen after a short time.

Caution

As long as no transport goods are sucked on, the signal tone signalises insufficient vacuum in the lines to the suckers, the vacuum control lamps are off and there is no way of inspecting via the vacuum obtained on the two vacuum control meters.

Working Cycle

The surface must be absolutely free of dust, rust particles, water and similar. Clean the surface with glass-cleaner, detergent or similar.

If it is necessary to clean the goods to be transported, use a fat solvent that evaporates without any residue, such as Nitro or brake-cleaner.


The suction pads must not be covered by the protective hood when the goods to be transported are sucked on.

Use the rotation and/or swivelling device to determine the position of the carrier into which the transported goods are to be sucked on.

Position the VSG 600 KL B on the respective goods to be transported


Caution

- An uneven (A) load distribution is not permitted during rotation!
- Ensure an even (B) load distribution during rotation.



Caution

- Top-heavy (C) load distribution is not permitted during swivelling.
- (D) load distribution near the ground is not permitted during swivelling.
- Ensure bottom-heavy (E) load distribution during swivelling.



Check that all suckers on the surface are clean and have full contact and, if necessary, press on or align a sucker that is not making contact until it is in the correct position. If this is not done, a vacuum cannot build up and the VSG 600 KL B can therefore not lift the material. Switch on the device and set the two suction/release valves to the suction position one after the other.

Read the achieved vacuum from the two inspection vacuum meters.

If 0.72 bar vacuum has been obtained in each of the two vacuum circuits, the pumps switch off, the signal tone goes out and the vacuum control lamps are lit. The transport procedure can now be carried out.

Caution

If the extensions have been attached, the support suckers must be connected to the vacuum reserve tanks by the vacuum couplings.

Danger

- Do not convey loads over persons or machines.
- If the vacuum sinks below -0.65 bar in one of the vacuum circuits during transport work, a signal tone sounds. In this case, try to set down the load as soon as possible so that it does not fall down

The transported goods are guided from the side, which means that the operator stands as far as possible from the transported goods in order to guide them.

To rotate or swivel the transported goods, the corresponding locking mechanism is used. During this procedure, the transported goods must always be positioned according to the drawing (B) or (E). It must also be ensured that the rotation or swivelling motion can be performed without danger and that no damage occurs to the transported goods. Larger panes should be additionally held.

If you want to release the transported goods, both suction/release valves must be set to the RELEASE position.

The vacuum drops and the cross arm releases itself from the transported goods. If the two inspection vacuum meters indicate 0, the procedure is completed. It can occur that the VSG 600 KL B remains stuck to the transported goods, but they are released again by the VSG 600 KL B which can lead to a small shock that shakes the transported goods. Therefore, hold on tightly to the transported goods during the release procedure.

Switching off

After completing the transport work, switch the device off in order not to drain the battery unnecessarily.

Charging the battery

Check the VSG 600 KL B for any externally recognisable damage or flaws.

Compare the connection on the power supply network with regard to voltage, current, and mechanical connection (plug connection) with the necessary data for the vacuum pumps: If they do not correspond, the machine may not be operated.

Connect the VSG 600 KL B to the mains power supply at the plug using an extension cable.

The charging procedure can be checked in voltage display after the Test button has been pressed.

After the charging procedure is completed, a value of 100% must be visible in the voltage display when Test button is pushed.

The battery is charged after a maximum of 24 hours.

Remove the extension cable from the mains power supply

This completes the charging.

Note

If the battery is not charged, the VSG 600 KL B cannot be used in mains operation.

During the charging procedure, the VSG 600 KL B must be switched off. This means that you should not work with it as the charging device or the battery will be damaged.

Troubleshooting

Pumps no longer perform correctly

The machine no longer reaches -0.72 bar vacuum.

Please check whether all suckers contact the transported goods cleanly; align them if necessary.

Check the suckers and hose lines for possible damage and replace them if necessary.

Check hose clamps for firm fit and tighten them if necessary.

Leak check for the entire system

You can perform a leak check of the two independently functioning vacuum circuits to find the leak as follows.

First of all, you should check the entire vacuum circuits with all suckers and the hose lines to both vacuum circuits. To do so, it is necessary to set all suckers on a gas-impermeable, flat material (for example, a metal or glass sheet) that can be sucked up. Then switch the device on and set the two suction/release valves to Suction one after the other. When the maximum achievable vacuum, as a rule approx. -0.72 bar in each vacuum circuit is achieved, set the main switch to OFF. Read the achieved vacuum from the vacuum meters and record the value in writing. The indicators of the vacuum meters should only change slightly within the next fifteen minutes, not more than 5%. If the result of this test is positive, the vacuum lifting device is tight and you can work with it without risk. If a leak is detected even in only one vacuum circuit, the device is not in working order and must not be commissioned. The leak must be corrected immediately or the porous material replaced.

Caution

The attached support suckers must be checked to see whether they are leak-tight.

Caution

The VSG 600 KL B must **NEVER** be commissioned with only **one** functional vacuum circuit.

Electrical malfunction

Vacuum pumps do not start when the device switch is actuated

- Vacuum supply sufficient. Device running correctly.
- Battery flat? Press button Test to check voltage display. Run machine in mains operation or charge battery.
- Check safety cutout.
- Have motor cable on pumps checked by an expert for any possible cable breakage.
- Vacuum monitor for switching point P2 defective? Replace

Vacuum pumps do not switch off when -0.72 bar vacuum is reached.

- Vacuum monitor P2 defect. Replace.

No warning signals

- Vacuum above -0.65 bar? Device OK.
- Vacuum monitor P1 defective? Replace.
- Signal buzzer defective? Replace.

Maintenance

Note

Please note that the trades association requires an annual inspection of vacuum lifting devices by a specialist, in accordance with the accident prevent regulations (VbG 9a-prEN 13155:1998). If you do not have a suitable staff member, we offer a maintenance contract for our vacuum lifting devices which includes annual maintenance including testing and certification. Please contact us for details.

Heavydrive LLC
3414 Peachtree Road NE, Suite 1500
Atlanta, GA 30326
Phone: +1 470 407 4352

The suckers

The suckers must be cleaned occasionally with fat solvent that evaporates without any residue, such as Nitro or brake-cleaner.

Please do not use a solvent (such as gasoline or similar substances). Never treat the suckers with talc, lubricants, or smoothing agents, as this impairs the adhesion of the suckers, causing the transported goods to slip from them.

The vacuum lines

The hoses must be inspected occasionally for visible cracks, etc. Replace defective hoses immediately!

Leak check

A leak test of the two independently functioning vacuum circuits must be performed at least once a week. You should check the entire vacuum circuit with all suckers and the hose lines.

To do this, it is necessary to set all suckers of the vacuum cross bar on a gas-impermeable, flat material (for example, a metal or glass sheet) that can be sucked up. Switch the device to On using the On/Off switch and set the suction switch to On. When the maximum achievable vacuum, as a rule approx. -0.72 bar in each vacuum circuit, has been achieved, set the suction switch to Off and switch off the device.

Read the vacuum obtained from the vacuum meters and record the value in writing. The indicator of the vacuum meters should only change slightly within the next 15 minutes, not more than 5%. If the result of this test is positive, the vacuum lifting device is tight, and you can work with it without risk.

If the test of only one of the vacuum circuits is negative, you can repair the leak and seal it or replace the leaking material, as described in the Troubleshooting chapter. The leak must be corrected immediately or the porous material replaced.

Caution

Always check that the support suckers are tight.

Caution

Always check the operational safety of the pump and the other elements before starting work / commissioning.

Caution

The VSG 600 KL B must **NEVER** be commissioned with only one functional vacuum circuit.

Technical data

Manufacturer:	Heavydrive LLC
Designation:	Vacuum suction system (battery operated)
Type:	VSG 600 KL B
Serial number:	
Year of manufacture:	
Operating instructions:	Art. no: VSG 600 KL B
Manufacturer's address:	Heavydrive LLC 3414 Peachtree Road NE, Suite 1500 Atlanta, GA 30326 Telefon: +1 470 407 4352

Temperature range

Operating temperature	-1 to +40°C (ambient)
Storage temperature	room temperature, not under 0 degrees

Dead weight with 4 extensions 93kg / 198.42 lbs

Frame size

Height:
Width:
Depth:

Vacuum tank

Hose connection 1st vacuum circuit 0.3 litre / 2nd vacuum circuit 0.3 litre

6 mm





One vacuum pump / vacuum circuit

Supply voltage: 12 V, DC
Nominal current: approx. 8A

Two batteries

Supply voltage: 12V, DC
Nominal capacity: approx. 7 Ah

Dimensioning outer edge of suction pad, overall depth



Carrying capacity of the VSG 600 KL B

All specifications regarding carrying capacity are based on an evenly distributed load.

Furthermore, all suckers must also have sucked on to the transport goods.

VSG 600 KL B delivered with suckers type T-15 / T-15W

Sucker type T-15 / T-15W

Diameter:

320 mm / 12.6"

Carrying capacity on smooth, clean, dry

Surface with 60% vacuum

Vertical:





150 kg / 330.69 lbs

Horizontal:


150 kg / 330.69 lbs

Vacuum connection:


9 mm



Wiring diagram VSG 600 KL B



Wiring diagram of the VSG 600 KL B with radio remote and cable remote control




Options for the VSG 600 KL B

Lowering cylinder

A lowering cylinder with ball valve or throttle valve which makes lowering the transported goods easier during swivelling.

Remote control with cable

A remote control with a spiral cable for releasing the transported goods.



1. cord switch suction circuit 1
Press=suction=pull=release
2. cord switch suction circuit 2
Press=suction=pull=release


Caution

When operating the remote control, the manually operated suction/release valves must always be set to SUCTION.

After the transported goods have been released, the cord switch must be restored to the SUCTION setting.

Remote control with radio control

A remote control with radio control for releasing the transported goods.



1. Not allocated
2. Radio control ON / OFF
 Switching on
 Turn to the right to Start
 then back to ON
 Switching off
 Turn to the left to OFF
3. To release
 Press both buttons at the same time

Activating the radio remote control

Switch on the device and plug on the remote receivers.
 Switch on the radio remote control. When the radio connection is active, the yellow control lamp on the device is lit.

Note

Every time the device is switched on, the radio connection has to be activated again.

Caution


When the radio remote control is in operation, the manually operated suction/release valves must always be in the SUCTION position.

To release the transported goods, both buttons have to be pressed at the same time.

Spare parts list for VSG 600 KL B

Quantity	Designation
1	Suspension eye
2	3/2 way sliding valve suction/release
2	Vacuum meter 50mm 1/8"
1	Chargert C-Tek 0.8A
6	Suction pad T-15 / T15W
1	Push-button selector switch
1	Buzzer (horn) 12V DC
1	Test button, push button
1	Charge indicator 12 V DC
2	LED indicator lamp 12V green
1	LED indicator lamp 12V yellow
1	Main fuse 15A
2	Pump fuse 7.5A
2	Vacuum pump DC Kappel
1	Battery 12V DC 7Ah
1	One-way valve SMC
2	Vacuum monitor type 625 (P1)
2	Vacuum monitor type 625 (P2)
2	1/4" Vacuum S.S. couplings for extensions
Options	
1	Lowering cylinder
1	Remote control complete with spiral cable With 2 cord switches (suction/release)
2	3/2 magnetic valve 1/8" 12V DC
1	Radio receiver
1	Radio remote control




Dimensions of the VSG 600 KL 6 B



Dead weight of the VSG 600 KL 6 B special version

See nameplate



Dimensions of the VSG 600 KL 6 B



Dead weight of the VSG 600 KL 6 B special version

See nameplate

Dimensions of the VSG 600 KL 6 B



Dead weight of the VSG 600 KL 6 B special version

See nameplate